

Quickstart

V1.0

aquaBAR HighColor+

Lichtsteuerung
Light Control



Lieferumfang

- 1 St. aquaBAR HC+ Beleuchtung
- 1 St. Stahlseilaufhängung
- 1 St. Netzteil
- 1 St. Kaltgerätekabel
- 1 St. WiFi Anschlussbox
- 1 St. Quickstart
(Bedienungsanleitung finden Sie unter <https://aqualeds.de/support/>)

Installation

1



Verbinden mit WiFi Anschlussbox

2



WLAN-Netzwerk
#aquaLEDs.de_Lighting+XXXX

Öffnen der Konfigurationsseite

3



IP-Adresse über Browser aufrufen
<http://192.168.1.1> bzw.
<http://lighting.local/> oder
<http://lighting/>

Sobald die Steuerung im Heimnetzwerk integriert ist, kann nur noch über <http://lighting.local/> oder <http://lighting/> drauf zugegriffen werden.



Firmware Update

Updates können unter **Einstellungen** vorgenommen werden.

- Bei Integration der Steuerung ins Heimnetzwerk, können Updates über den Button **Update Automatisch** mit Internetverbindung durchgeführt werden.

- Für ein manuelles Update rufen Sie bitte die Seite: <http://aqualeds.de/update> auf. Anschließend klicken Sie auf den Button **Update Controller Manuell** -> Überspringen und wählen dann die heruntergeladene Datei aus. Drücken Sie dann auf **Update** und warten einige Minuten, bis das Update abgeschlossen ist.



Farbenbedeutung der Status LED



Blinkt weiß
Die Steuerung baut ein Netzwerk auf und startet den Tagesverlauf



Blau - Masterbetrieb
Das Netzwerk wurde erstellt oder die Steuerung hat sich mit dem Heimnetzwerk verbunden




Grün - Slavebetrieb
Die Steuerung hat sich mit der Mastersteuerung verbunden



Blinkt orange
Ein Softwareupdate wird durchgeführt. Bitte warten Sie bis die Steuerung aufgehört hat zu blinken.



Sicherheitshinweis Safety Instructions

 Platzieren Sie das Gerät an einem geeigneten Ort, der sicherstellt, dass Kontakt mit Wasser ausgeschlossen ist.

Place the device in a suitable place, which ensures that contact with water is excluded.

aquaLEDs.de UG
Kanalstraße 12/1
72669 Unterensingen

Tel.: +49 (0) 157 389 764 89
www.aquaLEDs.de
info@aquaLEDs.de

aquaLEDs.de



Scope of delivery

- 1 pcs. aquaBAR HC+ Lighting
- 1 pcs. Hanging kit
- 1 pcs. Power supply
- 1 pcs. Power cord
- 1 pcs. WiFi junction box
- 1 pcs. Quickstart

(Operating manual can be downloaded by <https://aquaLEDs.de/support/?lang=en>)

Installation



aquaLEDs.de



Connect with WiFi junction box

2



WiFi network
#aquaLEDs.de_Lighting+XXXX

Open the configuration page

3



Call up IP address via Browser
<http://192.168.1.1> resp.
<http://lighting.local/> or
<http://lighting/>

As soon as the controller is integrated into the home network, the controller can only be accessed via:
<http://lighting.local/> or <http://lighting/>

aquaLEDs.de



Firmware Update

Updates can be executed by **Settings**.

- When the controller is integrated into the home network, updates can be done automatically by using the **Automatically Update** (Requires Internet connectivity) button.

- For a manual update please call the page:
<http://aquaLEDs.de/update>
Then click on the button **Update controller manual** -> skip and select the downloaded file.
Press **update** and wait some Minutes until the update is completed.

aquaLEDs.de



Color meaning of the status LED



White flashing
The controller sets up a network and starts the daily routine



Blue - Master operation
The network has been created or the controller has connected to the home network



Green - Slave operation
The controller has been connected with the master controller



Orange flashing
A software update is executed.
Please wait until the controller has stopped blinking.

aquaLEDs.de

